

HONDA / VANGUARD ENERGY

Voltage / Freq. / Phases	Model	Engine	POWER				Rope Start	Electric Start	Electric Start by Signal	Mains Fail Automatic system	Rental Park Version	Electric panel* (EC standard) with IP44 sockets	Special IP45 electrical panel* with IP67 sockets	Wheel & handle kit	High capacity fuel tank
			Voltage (V)	Engine (HP)	Genset (W)	Alternator (VA)									
230Vac 50Hz 1phase	G 3000 H K	Honda	230	4,8	2.200	2.200	x	---				x		x	x
	G 3500 H K	Honda	230	4,8	2.400	3.500	x	---			x	x		x	x
	G 4000 H	Honda	230	5,5	3.000	3.500	x	---				x		x	x
	G 5000 H	Honda	230	8,0	4.000	4.100	x	x	x	x	x	x	x	x	x
	G 6000 H	Honda	230	8,0	4.200	7.000	x	x			x	x	x	x	x
	G 7000 H	Honda	230	11,0	5.600	7.000	x	x	x	x		x	x	x	x
	G 8000 H	Honda	230	11,0	6.000	8.500	x	x			x	x	x	x	x
	G 12000 H	Honda	230	21	9.600	10.000	---	x	x	x	x	x	x	x	x
	G 5000 V	Vanguard	230	8,0	3.900	4.100	x	---						x	
	G 7000 V	Vanguard	230	11,0	5.600	7.000	x	---				x		x	x
	G 8000 V	Vanguard	230	11,0	6.080	8.500	x	---				x		x	x
	G 10000 V	Vanguard	230	15,0	8.000	10.000	x	x	x	x		x		x	x
	G 12000 V	Vanguard	230	17,5	9.600	10.000	---	x	x	x		x		x	x
230/400V 50Hz 1/3~	G 5 TF V	Vanguard	400/230	8,0	3.900	5.500	x	---						x	
	G 5 TF H	Honda	400/230	8,0	4.000	5.500	x	x	x	x	x	x	x	x	x
	G 7 TF V	Vanguard	400/230	11,0	5.600	7.000	x	---				x		x	x
	G 7 TF H	Honda	400/230	11,0	5.600	7.000	x	x	x	x		x	x	x	x
	G 8 TF V	Vanguard	400/230	11,0	6.080	10.000	x	---			x	x		x	x
	G 10 TF V	Vanguard	400/230	15,0	8.000	10.000	x	x	x	x		x		x	x
	G 12 TF V	Vanguard	400/230	17,5	9.800	12.500	---	x	x	x		x		x	x
	G 12 TF H	Honda	400/230	21	10.000	12.500	---	x	x	x	x	x	x	x	x
	G 15 TF H	Honda	400/230	22	12.000	15.000	---	x	x	x		x	x	x	x

SCOPE OF SUPPLY:

- Engine/alternator assembly mounted on steel frame with anti-vibration pads.
- Single phase sets: 2 single phase sockets. Thermal trip.
- Three phase sets: 1 single-phase socket with thermal trip and 1 three-phase socket.
- Sockets according EC standards. For others, please consult.
- Electric start sets include battery.

* Electric panel features voltmeter, circuit breaker, hour runs meter, earth leakage protection and connected indication lamp.

Power factor: 1,0 for single-phase gensets and 0,8 for three-phase units.